

## Technical Bulletin

# SelectShot™ Parameters

Starting the 2021 Planting Season

New operating parameters have been set for the operation of the SelectShot system. The updated parameters for operating in Auto mode are listed below. Speed is on the left side of the chart, with row spacing along the top. The box that coincides with your selected operation is a seed population (x1000) max cutoff.

		Row Spacing (inch)			
		15	20	30	38
Speed (mph)	1	200	200	200	200
	2	200	200	178	141
	3	200	178	119	94
	4	178	134	89	70
	5	143	107	71	56
	6	119	89	59	47
	7	102	76	51	40
	8	89	67	45	35
	9	79	59	40	31
	10	71	53	36	28
	11	65	49	32	26
	12	59	45	30	23
	13	55	41	27	22
		Thousand seeds/ acre			

Type in the value to get the correct value in the SelectShot software

The software automatically converts the value to K seeds/acre

Example: 59 = 59,000 seeds/acre