

## **Service Bulletin**

## CapstanAG Valve Service Procedure

The new valve design requires new service details.




Figure 1

Figure 1: Hold the coil (1) stationary while tightening the flynut (2). If the coil is rotated while tightening the flynut, damage to the spoke O-ring (3) can occur and cause the valve to leak.




Figure 2

Figure 2: To service the valve components, remove the retaining clip (1). Use the retaining clip to remove the orifice insert (2) to service the plunger (3).

©2022 Capstan Ag Systems, Inc. All Rights Reserved. | All trademarks are owned by Capstan Ag Systems, Inc. This product may be covered by one or more U.S. Patents. For more information go to <a href="www.BlendedPulse.com">www.BlendedPulse.com</a>