
Fast 9518TF 100ft 101' 7 section on 15" spacing

Make	FAst
Model	9518TF 100'
Year	

Total Nozzles	81
Nozzle spacing (IN)	15
Number of sections	7

Section Number	Number Nozzles	VCM Size	VCM Orientation	Extension Length
Section 1	12	15	Right	45
Section 2	12	15	Right	30
Section 3	12	15	Right	10
Section 4	9	9	Left	5
Section 5	12	15	Left	15
Section 6	12	15	Left	30
Section 7	12	15	Left	50
Section 8				
Section 9				
Section 10				
Section 11				
Section 12				



40620 Production release

DESCRIPTION

DATE

7/18/22

By KP

REV.

ECR

Boom Folds and Hub mounting - Count number of nozzles to each point				
Boom Breakaway		Nozzle count Dimension A		
Outer Fold	12	Nozzle count Dimension B(if Applicable)		
Inner Fold	24	Nozzle count Dimension C		
Primary Fold	36	Nozzle count Dimension D		
Gateway Location	39	Nozzle count Dimension E, Center mount = 0		

